

# GASOLINE PRESSURE WASHER

# **OWNERS MANUAL**



# CONTENTS

- 1 .....GENERAL SAFETY INSTRUCTION  
MAINTENANCE AND STORAGE
- 2 .....GETTING TO KNOW YOUR PRESSURE WASHER  
ASSEMBLY
- 3 .....ASSEMBLY
- 4-8 .....OPERATION AND USE
- 9-11 .....MAINTENANCE
- 12 .....TROUBLESHOOTING
- 13 .....PUMP PARTS
- 14 .....DECLARATION OF CONFORMITY

# GENERAL SAFETY INSTRUCTIONS

- Read instructions carefully before operating this product.
- This product is for outdoor use only.
- Keep bystanders away.
- Ensure the engine is stopped before carrying out adjustments, cleaning or maintenance.
- Always turn off the engine and water supply when finished.
- Do not use the product if found to be damaged.
- Only use with detergents specified by the manufacturer. Other chemicals may compromise the safety of the product.
- Do not direct the pressure jet towards mechanical parts containing lubricant grease.
- Clean vehicle tyres from a minimum of 50cm to avoid damage by the high pressure jet.
- Do not point high pressure jets at people, animals, live electrical parts or the product itself.
- Do not use accessories such as hoses and connections that are not advised by the manufacturer.
- Engage the high pressure safety catch located on the gun when not in use.
- Do not step/stand on the high pressure hose.
- Ensure the nozzle is securely attached before using the Product. High pressure can cause it to be fired from the lance with considerable force, and could cause injury damage.
- Be ready for the kick-back force and the sudden torque on the spray assembly when operating the trigger.
- A high pressure jet can remove paint and other surface finish. It can also damage tarmac and grouting.
- Switch off completely when not attended.
- The hose is designed specifically for operation with high pressures. Take care to avoid damage that may prevent correct operation of the product.
- This product is not to be used by children or anyone with reduced capabilities.
- Always completely unwind the high pressure hose prior to operation.
- Make sure that the machine is switched off before unwinding the high pressure hose, and take care not to pull the machine over.
- Do not let the high pressure hose contact the hot engine exhaust.
- Do not use this product indoors.
- Keep exhaust emissions away from air intakes.




Model	G150	G200/GE200	G250/GE250
Permissible pressure	17Mpa	22Mpa	27.5Mpa
Rated pressure	13.5-15Mpa	18.2-20Mpa	23-25Mpa
Max flow	12.6 L/min	15 L/min	18 L/min
Engine	7-8 HP	9-10 HP	13-15 HP
Rated rotation speed	3400RPM	3400RPM	3400RPM
Allowable temperature	0-60°C	0-60°C	0-60°C

# MAINTENANCE AND STORAGE

- Do not attempt to modify the product in any way.
- To ensure good operating condition arrange regular servicing from an authorising agent.
- Only use replacement parts supplied by the manufacturer
- Only use fresh, clean and good quality fuel in the engine.
- Never operate the engine without oil.
- Never refuel in close proximity to naked flames, sparks or other sources of ignition e.g. cigarettes.
- Do not refuel when the engine is hot.
- Wipe up and correctly dispose of any fuel spillage immediately with a suitable medium.
- Move away from the refuelling areas before restarting the engine. Store fuel for short periods only in a suitable container away from heat and direct sunlight.
- Clean the pressure washer thoroughly after each use.
- Regularly check external nuts and fixings to ensure vibration caused by normal use has not begun loosen them. Remove the spark plug ignition lead from the back of the spark plug and position the lead to avoid accidental reconnection.
- Store the machine in a secure dry location out of reach of children.
- Empty the fuel tank before storage.
- Make sure to empty the product of any excess water from your hose or gun.
- Do not leave product in freezing conditions as this will cause damage the product.

# GETTING TO KNOW YOUR PETROL PRESSURE WASHER



- 1. Engine
- 2. Pump
- 3. Upper Frame
- 4. High Pressure Hose
- 5. Hook
- 6. Wheel
- 7. Lower Frame
- 8. Engine Recoil Starter
- 9. Exhaust Silencer (HOT do not touch)

## ASSEMBLY

**NOTE:** Every machine is tested during the production, so there may be a few drops of water inside the pump assembly.

FIG. 1



(FIGS. 1 - 3)

Push bar A down, Lift handle B.

FIG. 2



Then Lift bar A back up.

FIG. 3



Locate the hose and the lance onto the upper frame and secure using the nuts and bolts provided.

# ASSEMBLY

FIG. 4



FIG. 5



## TO ASSEMBLE THE WHEELS (FIGS. 4 - 5)

Ensure the appliance is kept in the upright position. Insert the axle bar into the axle support tube on the lower frame, tighten the bolt to secure in place.

Fit a wheel to the axle and secure using the locking nut provided. Repeat this process for each wheel.



### WARNING:

The engine is not provided with oil. It's necessary to fill the unit before starting the engine.

FIG. 6



## ENGINE OIL (FIGS. 6 - 7)

The engine is not provided with oil. It is necessary to fill the oil before starting the engine. The engine has two oil fill points at the front and back of the engine. Remove the desired cap and fill with the engine oil specified to the upper level mark. Install the oil filler cap.

FIG. 7



oil filler caps.

FIG. 8



## PUMP OIL (FIGS. 8 - 10)

**WARNING:**  
Must take off this red plastic part of the pump.

FIG. 9



### WARNING:

Check the capacity of the pump oil and see if it's reached  $\frac{1}{2}$ .

FIG. 10



### WARNING:

Install the yellow plastic breather plug in place of the black shipping plug.


FIG. 11



## HIGH PRESSURE CONNECTION (FIGS. 11 - 14)

Connect the high pressure hose to the unit's high pressure outlet.

FIG. 12



Connect the high pressure hose to the trigger B. Insert the lance C into the trigger. Press firmly against the spring tension and twist the coupling into the locked position. Insert the required nozzle by retracting the coupling at the end of the lance, ensure the nozzle is inserted securely

FIG. 13



### INSERTING A NOZZLE (FIG. 13)

To insert a nozzle, pull back the locking collar at the end of the lance, insert nozzle and release the collar. This will lock the nozzle in place. Ensure the nozzle is inserted correctly. If not it can fly out and injure personnel or damage property.

FIG. 14



### CONNECTING THE HOSE (FIG. 14)

Connect the hose to the unit's water inlet connector (Max. 10 bar, max. temperature 40°C) and turn the water on completely.

## OPERATION AND USE

- WARNING:** The engine is not filled with oil. It is necessary to fill the unit before starting the engine. The engine will not produce a spark unless sufficient oil is inside.
- CAUTION:** Do not run the engine with high or low oil level as this can cause engine damage.
- CAUTION:** Only use unleaded gasoline.
- CAUTION:** Avoid damaging your hose by ensuring it does not touch the hot exhaust during and after use.
- CAUTION:** Avoid damaging your pump by ensuring the water supply is clean and free of any foreign objects.
- CAUTION:** Inlet water temperature must not exceed 40°C and 1Mpa
- CAUTION:** Never let the appliance operate for more than 2 minutes with the spray gun in the closed position.
- CAUTION:** Never operate the pressure washer with repeated and rapid on and off movements of the trigger

### WATER SUPPLY FROM THE WATER MAIN

- Connect a water supply hose (not supplied) to the water inlet connection of the pressure washer.
- Turn on the water supply and pull the trigger until water is continually flowing out of the nozzle.

### WATER SUPPLIER FROM A CONTAINER

- Unscrew the coupling part for the water inlet.
- Screw the suction hose with filter (not included) onto the water connection of the unit.
- Hang the filter in the container.
- Vent the unit before operation.
- Unscrew the high pressure line at the high pressure outlet of the unit.
- Switch on the unit and let it run until water is free of bubbles at the high pressure outlet.
- Switch off the unit and screw on the high pressure hose again.

FIG. 15



Pull the trigger to eliminate trapped air and wait for a steady flow of water to emerge from the spray nozzle.

FIG. 16




To prevent accidental operation the trigger is fitted with a locking facility.

### NOTE:

In order to assist the first startup it is recommended to press the trigger during the pulling of the starter handle.

# OPERATION AND USE


FIG. 17



## STARTING THE ENGINE (FIG. 17 - 20)

Push the fuel lever to the right (On position).


FIG. 18



Push the choke lever to the left; closing the initial choke start up.

**NOTE:** Do not use the choke if the engine or air temperature is warm

FIG. 19



Turn the engine switch clockwise to the on position.

FIG. 20



Pull the black starting rope handle gradual until you feel resistance; then make a rapid pull.


**NOTE:** Return the starting rope handle gently to prevent damage to the starter assembly. Do not pull the rope all the way out as this can damage the starter assembly.

FIG. 21



Let the engine idle for a short while to preheat before pushing the choke lever to the right.

FIG. 22



When the appliance is in operation, the speed can be adjusted by moving the throttle control lever to the high position.

**NOTE:** There is a stop bracket on the throttle control lever, do not force this bracket as it can damage the engine.

FIG. 23



## STOPPING THE ENGINE (FIG. 23 - 24)

FIG. 24



In an emergency turn the engine switch anticlockwise to the off position to stall the engine. To stop the appliance normally use the following sequence.

Turn the engine switch anticlockwise to the off position. Then slide the fuel lever to the right **CAUTION:** When you have finished working turn off the engine. When the machine is switch off, always discharge the pressure by pressing the trigger.

# OPERATION AND USE

## ADJUSTING THE SPRAY PATTERN (Fig.25)

You have the choice of 4 different colour coded nozzles giving you different spray patterns to choose from:

### 0° nozzle (Red):

This nozzle delivers a pinpoint stream and is extremely powerful. It covers a very small area of cleaning. This nozzle should only be used on surface that can withstand this high pressure such as metal or concrete. Do not use on wood.

### 15° nozzle (Yellow):

This nozzle delivers a powerful 5 degree spray pattern for intense cleaning of small areas. This nozzle should only be used on areas that can withstand the high pressure from this nozzle.

### 25° nozzle (Green):

This nozzle offers a 25 degree spary patteren and can be used for powerful cleaning without causing damage to the targeted area.

### 40° nozzle (White):

This nozzle delivers a 40 degree spray pattern and a less powerful stream of water. It covers a wide area of cleaning. This nozzle should be used for most general cleaning jobs.

### Low pressure nozzle (Black):

This nozzle is used to apply chemicals or cleaning solutions. It has the least power stream.

FIG. 25



### NOTE:

Before using the pressure washer to clean patio paving slabs it is advisable to test a small area first, some paving slabs are manufactured from inferior materials and the use of a pressure washer could damage the surface.

## CLEARING A BLOCKAGE (Fig. 26)

If at any time the flow rate stutters or is inconsistent, release the trigger and switch "OFF" the machine. Squeeze the trigger to relieve any pressure and check the jet in the end of the lance for any blockage. If a blockage is suspected use some wire to clean the inside of the nozzle.

FIG. 26





# OPERATION AND USE

## SAFETY INSTRUCTIONS FOR THE ENGINE

- Before operating the engine, be sure to read all instructions carefully as injury or permanent damage to equipment may occur.
- Run the engine in a well ventilated area.
- Ensure the appliance is at least one metre away from building walls or other equipment.
- Keep the appliance away from flammable liquids such as petrol.
- Refuel in a well ventilated area with the engine switched off and avoid sparks or naked flames.
- When refuelling ensure that you do not overfill the fuel tank.
- If any fuel is spilled ensure it is cleaned up thoroughly before restarting.
- Ensure the fuel cap is located securely.
- The exhaust mufflers get very hot and will remain hot for sometime after the engine is switched off.
- Ensure the appliance is cooled before transporting or storing.



## PRE-OPERATION INSPECTION

### CAUTION:

Engine oil is a key factor in deciding the engine's performance. Do not use engine oil with additives or 2-stroke gasoline engine oil, as they do not have enough lubricating properties, which may shorten the engine's service life.

- Check the engine is on level ground.
- 10W30 is recommended for general all temperature use.
- Remove the dipstick and clean it.
- Re-insert the dipstick into the oil filler without screwing it in and check the oil level.
- If the oil level is too low add the required amount of engine oil to the oil filler mark. Replace the dipstick securely.

### CAUTION:

Running with insufficient engine oil may damage the engine severely.

FIG. 27



# OPERATION AND USE

## FUEL AND FUEL TANK:

Only use unleaded petrol or fuel with an octane number over 86. Using unleaded petrol or fuel will decrease the possibility of producing carbon deposit and prolong the engines service life. Never use old or polluted petrol or fuel or a mixture of petrol and engine oil. Make sure the fuel is free of dirt and water.

## CAUTION:

Handle fuel with care because it can damage plastic and painted surfaces. Remove the fuel filler cap and check the fuel level. If the fuel lever is too low, refuel the tank. Remember when adding fuel do not fill over the fuel filter shoulder.

## WARNING:

Petrol is extremely flammable and is explosive under certain conditions. Refuel in a well ventilated area with the engine stopped. Do not smoke or allow flames and sparks in the area where petrol is stored or where the fuel tank is refuelled. After refuelling make sure the fuel cap is returned securely. Be careful not to spill fuel when refuelling. Spilled fuel or fuel vapour may ignite. If any fuel is spilled make sure the area is dry before starting the engine.

## FUEL TANK FILTER (Fig.28):

After every 150 hours of running or every three months the fuel tank filter should be removed and cleaned. Remove the fuel tank filler cap and the filter, clean the filter thoroughly using environmentally friendly water based degreasing agent and re-fit.

## OIL LEVEL SWITCH:

The engine oil alarm is designed to prevent the operator starting the engine when the oil in the crankcase is insufficient. Running with insufficient oil will damage the engine. Once the oil level in the crankcase is too low, the engine oil alarm will stall the engine automatically to avoid damage while the engine switch is still ON.

FIG. 28



FIG. 29



## AIR FILTER (Fig.29):

After every 100 hours of running or every month, the air filter should be removed and examined for deterioration and cleaned. Clean the air filter thoroughly using environmentally friendly water based degreasing agent. Allow to dry fully then replace the air filter. Never run the engine without the air filter fitted.

## STORAGE:

If the engine is not to be used or is to be stored for more than one month the following storage procedure should be carried out.

- Drain all the fuel from the fuel tank and the carburettor ensure that all the fuel has been removed.
- Remove the spark plug and pour approximately one tablespoon full of clean engine oil into the spark plug hole. • With the ignition turned OFF gently pull on the recoil starter cord several times.
- Re-fit the spark plug and continue to pull the recoil starter cord until the piston is on the compression stroke (when resistance is felt) then stop pulling.
- Store the pressure washer in a dry well ventilated place under a cover to prevent any dust or debris from accumulating on the pressure washer.

## WINTER AND LONG TERM STORAGE:

If the pressure washer is not to be used for more than 3 months or if there is a danger of ice or frost during winter months the pump unit will require protection to prevent seizing and damage caused by freezing.

# MAINTENANCE

## EXHAUST CONTROL SYSTEM

With the engine running, carbon monoxide, nitrogen oxide and hydrocarbon are produced, and in certain conditions nitrogen oxide and hydrocarbon will react together to make smoke while carbon monoxide is toxic, so exhaust control is very important. The manufacturer decreases exhaust emissions by introducing poor-fuel carburetors and other devices to solve the problem. To keep the exhaust of your engine within the standard exhaust emission values, pay attention to the following:

## MAINTENANCE

Maintain the engine periodically in accordance with the maintenance schedule. The maintenance schedule is made out on the basis of normal use in normal conditions. If using under heavy load, dusty or wet conditions or in high temperature, more frequent maintenance will be necessary.

## REPLACEMENT OF PARTS

We recommend that you use parts that are supplied by the manufacturer or equivalent quality parts. Replacement parts of inferior quality may impair the effectiveness of the exhaust control system.

## MODIFYING

Modifying the exhaust control system may make exhaust emissions exceed statutory limits. Illegal modifications are:

- Dismantling or modifying any part of the air inlet or outlet system.
- Modifying or removing speed adjustment controls or connections which may result in the engine running outside its set parameters.

## PROBLEMS AFFECTING EXHAUST EMISSIONS

- Difficulty in starting or stopping.
- Erratic idling.
- Giving off black smoke or excessive fuel consumption.
- Poor ignition spark or no spark.
- Ignition too advanced. If you have any of these above problems please contact your dealer.

## CAUTION:

Before carrying out any maintenance to the machine release any pressure and remove the water connection.

## WATER SUCTION FILTER CHECKING

Check periodically in order to avoid deposits clogging it.

## SPARK PLUG MAINTENANCE

After every 50 hours clean the spark plug with a brush. If the insulator on the spark plug is damaged replace it immediately. Check the spark plug gap with a feeler gauge, the gap should be 0.7 - 0.8mm. If adjustment is necessary bend the side electrode carefully. Check the spark plug gasket is in good condition or replace with a new one. Screw in the spark plug to the bottom first by hand and then tighten by using a spark plug wrench. If a new spark plug is used, twist a A more turn after impacting the gasket. If using the original one twist e -1/4 more turn.

## WARNING:

The muffler is very hot during running the engine and for a prolonged period after stopping. Only service after the engine cools down completely. Unscrew two nuts and remove the exhaust elbow from the engine body. Unscrew five screws from the muffler guard and take it out. Unscrew from the spark plug eliminator and separate from the muffler. Clean the spark eliminator mesh with a wire brush. Reinstall the spark eliminator in reverse order of removal.


## CAUTION:

- Be careful not to damage the spark eliminator. Never use a damaged spark eliminator.
- The spark plug eliminator should be serviced at least once every 100 hours of operation so as to keep it in good condition.

## CARBURETOR IDLING ADJUSTMENT

Start and pre-heat the engine until it reaches normal working temperature. Obtain standard idling by adjusting the throttle fixing screw under the engine, Standard idling: 3400+300rpm.

# MAINTENANCE



## TRANSPORT

Transport with the fuel switch in the off position. Ensure the engine is cooled so as to avoid the risk of burns or fire.

## CAUTION:

Do not tilt the engine to avoid spilling fuel. Spilled fuel or fuel vapour may ignite.

**STORAGE** If the engine is not to be used for a long period of time ensure it is stored correctly. Make sure the storage area is dry and free of dust.

## PREPARE FOR STORAGE

Disconnect the spark plug. Put a spoonful of fresh engine oil into the cylinder and rotate the engine to distribute the oil evenly. Replace the spark plug. Pull the starting rope until you feel resistance and then keep pulling so as to align the arrow of the starting sleeve with the hole of the starter: This will close both the inlet and outlet valves to help prevent the engine rusting inside. Cover the engine to keep it free of dust.

## REMOVAL FROM STORAGE

Before re-using, service the engine in accordance with the instructions in the following table.



STORAGE TIME	SERVICE ITEM
Within one month	No service needed
One - Two months	Drain out original fuel of the fuel tank and refuel
Two months - One year	Drain out original fuel of the fuel tank and refuel
	Drain out the fuel in the carburettor <b>1</b>
	Empty the deposit cup <b>2</b>
Above One year	Drain out original fuel of the fuel tank and refuel
	Drain out the fuel in the carburettor <b>1</b>
	Empty the deposit cup <b>2</b>
	Move the engine from the storage place, and start up

**1** Unscrew the drain plug and drain out the fuel in the carburetor:

**2** Turn off the engine switch first, disconnect the deposit cup and empty it.

## NOTE:

Do not dump oil containers or discarded engine oil into the ground. For environmental protection take discarded engine oil in a closed container to a recycling station.

## WARNING:

Fuel is extremely flammable and explosive under certain conditions. Keep cigarettes, naked flames and sparks away from operating site.

# MAINTENANCE

To keep the engine in sound condition, the user should maintain it according to the table below.

Item		Each time	First month or 20 hours	Each month or 50 hours	Each 6 months or 100 hours	Each year or 300 hours
Engine oil	Oil level check	✓				
	Replace		✓		✓	
Reduction gear oil	Oil level check	✓				
	Replace		✓			
Clean	Check	✓				
	Air cleaner			✓ <sup>1</sup>	✓ <sup>1</sup>	
	Replace					✓ <sup>2</sup>
Deposit cup	Clean				✓	
	Clean, adjust				✓	
Spark plug	Replace					✓
	Clean				✓	
Spark eliminator	Clean				✓	
Idling	Clean, adjust					✓ <sup>2</sup>
Valve clearance	Clean, adjust					✓ <sup>2</sup>
Fuel tank & fuel filter	Clean					✓ <sup>2</sup>
Fuel supply line	Check					✓ <sup>2</sup>

## CAUTION:

Use parts that are supplied by the manufacturer, otherwise damage to the engine may occur.

## WARNING:

Stop the engine before servicing. If servicing is required with the engine running ensure there is good ventilation in the area. Exhaust emissions contain toxic carbon monoxide which may cause injury or be fatal if inhaled.

## ENGINE OIL REPLACEMENT

Place the machine on a level surface and warm up the engine for several minutes. Then stop the engine. Remove the oil filler cap Place an oil pan under the engine. Remove the oil drain plug so that the oil can be completely drained. You will need to use a tube or other similar device to prevent the oil leaking onto the frame of the pressure washer. Check the oil drain plug, gasket oil filler cap and O-ring and if damaged replace. Reinstall the oil drain plug. Add engine oil up to the upper level of the dipstick.

## NOTE:

Do not dump oil containers or discard engine oil into rubbish boxes or into the ground. For environmental protection take discarded engine oil in a closed container to a recycling station.

## NOTES:

\* Only for inside ventilating double-core carburettors.

\*\* Only for paper core air cleaners. 1. More often than in schedule if used in dusty conditions

2. Items to be done by dealer unless you are fully trained and equipped to do so.

## PUMP NOTICE

1. For the convenience of transport, Pump without machine oil, and breather plug is not installed. Please add 15W/40 or 30 machine oil before using. Machine oil quantity is subject to slightly not too oil lens centre line, then install the breather plug.
2. After using 20 hours of the new machine, pour the machine oil out, and add the appropriate amount of kerosene, fuel is according to standard a little than oil lens centre line. Operate the pump without load in 10-15 seconds, then close the machine and pour out the kerosene, add the new oil.
3. Please check the oil mass before using .If the oil level is less than 1/2 oil lens , it's needs to add the oil to the oil lens centre line.
4. Accumulative use after 100 hours , change the oil in the same way. And every 100 hours to change the oil. It's very important to Extend the service life of the pump.

# TROUBLESHOOTING


## PUMP TROUBLESHOOTING

TROUBLE	PROBABLE CAUSE	REMEDY
Fluctuating pressure	Pump sucking in air	Check connection are tight
	Valves dirty, worn out or seized	Contact customer helpline
	Blocked jet	Remove blockage using jet cleaning tool
Water leakage from pump	Seals worn out	Contact customer helpline
The pump does not reach the required pressure	Pump sucking in air from connections or hose	Check tightness of all connections
	Suction/delivery valves are clogged	Clear or replace valves. Have machine checked by Service Centre
	Unload valves are stuck	Loosen and re-tighten regulating screw
	Lance or nozzle worn out	Check and/or replace
Pump is running but no water delivery	Kinked inlet and or pressure hose	Check, straighten and replace if required
	Blocked inlet filter	Remove and clean filter
	Blocked jet	Remove blockage using the jet cleaning tool

## ENGINE TROUBLESHOOTING

FAULT	PROBABLE CAUSE		REPAIR	
Engine won't start	Insufficient compression	Loose spark plug	Tighten plug	
		Loose cylinder head bolt	Tighten bolt	
		Damaged gasket	Replace gasket	
Low engine output	Sufficient compression	<b>FUEL SYSTEM PROBLEMS</b>		
		No fuel supplied to combustion chamber	Insufficient pulling speed for starting rope	Pull rope sharply
			Foreign matter in fuel tank	Clean tank
			Clogged fuel line	Clean fuel line with dealers advice
			No fuel in tank	Supply fuel
			Fuel tap not open	Open tap
<b>FUEL SYSTEM PROBLEMS</b>				
Engine runs erratically	Combustion chamber supplied with fuel	Poor spark	Spark plug dirty with carbon or wet with fuel	Remove carbon or dry spark plug
			Damaged spark plug	Replace spark plug
		Good spark	Faulty magneto	Consult dealer
			Improper adjustment of carburetor	
			Insufficient pulling speed for starting rope	Pull rope sharply
Engine runs erratically	Wrong grade of fuel used		Check grade of fuel	
	Overloaded		Check the working conditions	
	Overheating			

# PUMP PARTS DRAWING



No.	Name	Qty	No.	Name	Qty	No.	Name	Qty
1	Screw	2	25	O-ring	3	49	Adjustable Spring Washer	1
2	O-Ring	5	26	Compress Ring	3	50	Adjustable Spring	1
3	M6X18 Inner Hexagon	10	27	Plastic Washer	3	51	Cupreous Connector	1
4	M6 Spring Washer	24	28	Main Water Seal	3	52	Adjustable Valve Core	1
5	Crank Case Bottom Cover	1	29	Crutch Ring	3	53	Valve Core O-ring	2
6	Crank Case	1	30	Outlet Hose	1	54	PTFE Blocker	1
7	Crank Case	1	31	Outlet Hose O-ring	2	55	Valve core Frame	1
8	O-ring 72X2.6	2	32	Inlet Hose	1	56	O-Ring	1
9	Bearing	1	33	Equal Tee Connector	1	57	O-Ring	1
10	Clip	1	34	Inlet connector	1	58	Adjustable Valve Head	1
11	Crank Case	1	35	Inlet O-ring	1	59	Adjustable Valve Base	1
12	Valve O-ring 20X2.4	12	36	Outlet Connector O-ring	2	60	Detergent Tube Connector	1
13	Valve	6	37	Screw Cap	1	61	Valve Base O-ring	1
14	Valve Cover O-Ring 23X2.65	6	38	Connection Base	1	62	O-Ring 7X1.9	1
15	Valve Cover	6	39	M6X20 Inner Hexagon Screw	4	63	Steel Ball	1
16	M6X55 Inner Hexagon	8	40	Frame Oil Seal	1	64	Pagoda Spring	1
17	Crank	1	41	Clip Ring	1	65	Equal Across Connector	1
18	Pole	3	42	Bearing	1	66	Bypass O-ring 9X2.4	1
19	Plunger Pin	3	43	Blocker	2	67	Bypass Valve Body	1
20	Smear Piston	3	44	Pump Head	1	68	Bypass Spring	1
21	Plunger Oil Seal	3	45	Adjustable Wheel Cover	1	69	Suction Wedge	1
22	Feet	3	46	Adjustable Wheel	1	70	Outlet Connector G1/2	1
23	Orientation Ring	3	47	Adjustable Set	1	71		
24	Water Seal	3	48	M4 Screw	1	72		